

Model 850 Install Instructions

Tools Needed:
Phillips Screwdriver
7/16" Wrench



Take nuts off of both bolts and remove both bolts. Move inner handle into position so that you can line it up with the holes. Reinsert bolts back through the openings, starting from the outside of the frame. Screw the nuts back on the bolts.

Make sure to tighten nuts securely.